ADVANCING Parts List: Intake shutter frame Shutter blades Opened Shutter's Pull-bar 3" expansion spring hooked into shutter pull bar. 1/8" cable for adjusting 24" Linear Actuator Pulled-in attachment brackets

61-LAP24 Linear Actuator Installation Instructions

1 ea. Linear Actuator 24 V DC w/ 2" stroke

2 ea. Attachment Brackets

2 ea Teks- #14x1"

1 ea. 1' of 1/8" adjust cable

1 ea. 1/8" cable clamp

1 ea. 3" extansion spring

1 ea. 3/4" S Hook

#2 Attach "S" Hook to shutter pull bar and spring.

#3 Adjust cable as needed to appropriate tension to Open/ Close shutter.

#4 Attach 2 wire leads to 24 V DC controlling device. Check for correct direction of Open/Close action.

#1 Attach Linear Actuator to bottom of frame of shutter and aligned with shutters pull bar.

