




All electrical connections must be made by a qualified, licensed electrician and in accordance with all state and local codes.



Aegis TEC Plus Wiring for a 2-Speed Fan

Settings Example: Fan #3 (relay #8) Set to 70° - Fan #4 (relay #9) set to 75° - Fan Temperature Gap set to 5°

Low Speed of Fan will turn on at 70° if temp rises above 75° high speed of fan will turn on. When the temp drops below 70° high speed will turn off and when below 65° low speed will turn off.

Aegis TEC Plus Settings

Config Menu:

- P0 = 2 - Number of Vents
- P1 = 0 - Number of Dep
- P2 = 4 - Number of Fans
- P3 = 0 - Number of Heaters
- P4 = 1 - First Vent Output
- P6 = 6 - First Fan Output

Two Speed Fan Contacts

